



# CLUB CAR DS CLAYS BASKET INSTALLATION INSTRUCTIONS

04-010

## INCLUDED:

- MADJAX CLAYS BASKET
- BRACKETS
- HARDWARE PACK



**1**  
Remove bolts from front struts.  
Retain all factory hardware.  
You will need it later.



**2**  
Using retained factory hardware,  
attach brackets to front struts.  
Tighten bolts.



## CLUB CAR DS CLAYS BASKET HARDWARE PACKS

### HARDWARE PACK 1

- (2) 8MM X 30MM SHOULDER HEX BOLTS
- (4) 8MM X 25MM SHOULDER HEX BOLTS
- (12) 8MM X 20MM X 2MM WASHERS
- (6) 8MM ANTI-SLIP NUTS

