

Fender Flare Installation Instructions

Turn the key switch OFF and remove the key, place the forward/Reverse handle in the NEUTRAL position (if applicable), engage the car brake, and chock the tires

Kit includes:

1 set of flares (2 Front, 2 Rear)
20 Plastic push fasteners

Tools Required:

Drill with 15/64" drill bit
Tape for holding fender flare
Pencil or marker for marking hole

INSTALL FLARES

- Hold front flares up to underside of the front body panel near the bottom of rocker panel.
- Temporarily use tape to hold fender flare in place
- Mark hole locations on body using a pencil or marker and drill holes using a 15/64" drill bit.
- Insert included plastic push fasteners firmly.
- Repeat steps on other 3 fender flares