

Step 1: Preparing the vehicle for Nerf Bar installation: Jack up the front and rear of E-Z-Go RXV. For safety use jack stands to support both the front and rear of vehicle.

Step 2: Remove the rocker panels

Step 3: Test fitting the Nerf Bars: From the outside- Align the Nerf bar so the front most mounting plate is centered inside the first “triangle” under the frame (see below).

Step 4: Locating and drilling rear mounting holes: (It will help to have an extra set of hands or a few clamps during this step.) Use a level and tape measure to ensure that the Nerf Bars are even and level on the cart before marking any mounting holes. Using a center punch and the holes in the Nerf Bars as a guide, mark the position of the mounting holes. Once all of the mounting holes are marked use a 1/8” drill bit to drill pilot holes where the Nerf Bars will mount. Drill out the 1/8” pilot holes using a 5/16” drill bit.

